



Stowaway Lid Brackets Installation

Required Tools

#1 square drive screwdriver (green)

Step 1

Set the tips of the screws into the predrilled pair of holes in the LID.

Hold the Stowaway Lid Bracket in place and drive the provided #6 x 1/2" flat head screws with a #1 square drive screwdriver, being careful to not over-tighten.



Step 2

Optionally, place a strip of loop fastener on the inside of the LID as a buffer to prevent wear between stored pedals and the interior of the LID.



For warranty information and more resources, visit our website at www.pivotalpedalboards.com

Extra copies of this guide can be downloaded at www.pivotalpedalboards.com/installation-guides.